

SAFE STARTUP GUIDE

How to Light Your Coyote Gas Grill

Open the hood. Stay back. Press, turn, confirm the flame.



Coyote C3CL36 shown | Product image courtesy of Coyote Outdoor Living

STOP IF YOU SMELL GAS. Do not attempt ignition. Turn all knobs OFF, shut off the gas supply if safe, move away from the grill, and contact a qualified technician or Coyote Support.

Before you light

Hood OPEN | Outdoors only | All knobs OFF | Burner area clear | Correct fuel supply

Light a main burner

- 1. Stay back.** Keep your head, body and arms away from the cooking surface; never lean over the grill.
- 2. Press and turn.** Press the selected burner knob inward and rotate it counterclockwise toward HIGH at a steady pace.
- 3. Listen and look.** At the click, the igniter sparks. Confirm the selected burner lights with a stable flame.
- 4. CL / SL models only.** After ignition, keep the knob pressed at HIGH for 6-10 seconds, then release so the thermocouple can hold the flame.

Know your model

Model	Ignition	Release the knob when...
C-Series	Press + turn to HIGH until the igniter clicks.	The burner is visibly lit and stable.
CL / SL	Press + turn to HIGH; hold 6-10 seconds after ignition.	The flame remains on after release.

NO FLAME AFTER THREE ATTEMPTS? Turn the knob OFF, keep the hood open, and wait at least 5 minutes before trying again. If it still will not light, shut off the gas and contact support. For the rear IR burner, follow the model manual.

Shut down safely

Turn every control knob clockwise to OFF, confirm all flames are out, then shut off the fuel supply as directed in the model manual.



Watch Coyote's official safety and lighting videos

coyoteoutdoor.com/new-grill | Support: 855-520-1559 | support@coyoteoutdoor.com

Official manuals: [Coyote Product Manuals & Guides](#)